


Promo Flag Assembly Instructions



11 ft. and 14 ft.



8 ft.

8 ft. Note:

If using outdoors, insert the ground stake and flag unit firmly into the ground, then use the L stakes and insert one into each corner of the metal cross bars to help stabilize the unit.

Parts List

UPIC: Pioneer ASI 78200 SAGE 56460



(A) Ground Stake

(A) Included with 8 ft. flag kits

(B) Ground Stake with Rotating Ball Bearing Stem

(B) Included with 11 ft. or 14 ft. flag kits

Bolt



Metal Cross Bars (2) (optional)



NOTE: Included with 8ft. Flag Kit or purchased as an accessory.

Flag Holder Base



L Stakes (4)



PVC Water Weight (optional)



NOTE: Included with 8ft. Flag Kit or purchased as an accessory. Water Weights can be used indoors or outdoors to add stability to your unit.

Flag Pole



Adjustable Ring

Flag Rod



Nylon Carrying Case



Flag



Flag Assembly 8 ft. flag



Flag Assembly 11 ft./14 ft. flag



Assembly Instructions for Indoor Use

- Step 1:** Attach the bolt to the bottom of the metal cross bars making sure the taller cross bar is on top of the shorter cross bar to form an X. (All four cross bar 'feet' should touch the ground. If they don't, then switch the cross bars.)
- Step 2:** Attach the flag holder base to the top of the cross bars. If using a PVC water weight once water is added place it over the top of the flag holder base.
- Step 3:** Attach the flag pole to the flag holder base.
- Step 4:** Feed the flag rod through the sleeve of the flag, making sure it goes all the way to the top to ensure stability.
- Step 5:** Take the flag with the inserted rod and insert the rod into the top of the flag pole. Pull the flag sleeve down over the flag holder base.
- Step 6:** Tie the black elastic cord to the grommet in the bottom of the flag sleeve. Take the other end of the black elastic cord, pulling it tight to keep the flag smooth, and wrap it around the black knob on the side of the flag pole to secure it. The flag pole has an adjustable ring that can be moved to straighten/smooth the flag. (Note: For the larger 14 ft. flag there is a snap on clip system instead of the black elastic cord.)

Assembly Instructions for Outdoor Use

- Step 1:** For the 8 ft. flag, attach the ground stake to the bolt underneath the metal cross bars and follow Steps 2-6 above.
- Step 2:** For the 11 or 14 ft. flags, attach the ground stake with rotating ball bearing stem directly to the flag pole and follow Steps 4-6 above.